```
I1 = imread("./images/image_left.png");
I2 = imread("./images/image_right.png");

% Convert to grayscale.
I1gray = im2gray(I1);
I2gray = im2gray(I2);

% Display both images side by side.
figure
imshowpair(I1,I2,"montage")
title("I1 (left); I2 (right)")
```

I1 (left); I2 (right)



```
% color composite demonstrating the pixel-wise differences between the images
figure
imshow(stereoAnaglyph(I1,I2))
title("Composite Image (Red - Left Image, Cyan - Right Image)")
```

posite Image (Red - Left Image, Cyan - Right I



```
% Collect Interest Points from Each Image
blobs1 = detectSURFFeatures(Ilgray,MetricThreshold=2000);
blobs2 = detectSURFFeatures(I2gray,MetricThreshold=2000);

% Visualize the location and scale of the thirty strongest SURF features in
II and I2.
figure
imshow(I1)
hold on
plot(selectStrongest(blobs1,30))
title("Thirty Strongest SURF Features In Il")
```

Thirty Strongest SURF Features In I1



```
figure
imshow(I2)
hold on
plot(selectStrongest(blobs2,30))
title("Thirty Strongest SURF Features In I2")
```

Thirty Strongest SURF Features In I2




```
% Find Putative Point Correspondences
[features1, validBlobs1] = extractFeatures(Ilgray, blobs1);
[features2, validBlobs2] = extractFeatures(I2gray, blobs2);


% Use the sum of absolute differences (SAD) metric to determine indices of matching features.
indexPairs = matchFeatures(features1, features2, Metric="SAD", ...
MatchThreshold=5);

% Retrieve locations of matched points for each image matchedPoints1 = validBlobs1(indexPairs(:,1),:);
matchedPoints2 = validBlobs2(indexPairs(:,2),:);

% Show matching points on top of the composite image, which combines stereo images.
figure
showMatchedFeatures(I1, I2, matchedPoints1, matchedPoints2)
legend("Putatively Matched Points In I1", "Putatively Matched Points In I2")
```



```
% Remove Outliers Using Epipolar Constraint
[fMatrix, epipolarInliers, status] = estimateFundamentalMatrix(...
 matchedPoints1, matchedPoints2, Method="RANSAC", ...
 NumTrials=10000, DistanceThreshold=0.1, Confidence=99.99);
if status ~= 0
    error('Failed to estimate the fundamental matrix. Check the quality and
quantity of matched points.');
elseif isEpipoleInImage(fMatrix, size(I1))
    error('The epipole is inside the left image. Check camera alignment or
consider using image rectification.');
elseif isEpipoleInImage(fMatrix', size(I2))
    error('The epipole is inside the right image. Check camera alignment or
consider using image rectification.');
end
inlierPoints1 = matchedPoints1(epipolarInliers, :);
inlierPoints2 = matchedPoints2(epipolarInliers, :);
figure
showMatchedFeatures(I1, I2, inlierPoints1, inlierPoints2)
legend("Inlier Points In I1", "Inlier Points In I2")
```



```
% Rectify Images
[tform1, tform2] = estimateStereoRectification(fMatrix, ...
  inlierPoints1.Location,inlierPoints2.Location,size(I2));

% Rectify the stereo images, and display them as a stereo anaglyph
[I1Rect, I2Rect] = rectifyStereoImages(I1,I2,tform1,tform2);
figure
imshow(stereoAnaglyph(I1Rect,I2Rect))
title("Rectified Stereo Images (Red - Left Image, Cyan - Right Image)")
```

ectified Stereo Images (Red - Left Image, Cyan - Right Ima

